


SPECIFICATIONS



OPERATING CONDITIONS

1. Water supply pressure : 0.05 ~ 0.75 MPa.
2. Hot water supply temperature shall be higher by 10°C. at least, than desired temperature of mixed water. (Recommendation: Hot water supply temperature =60°C)
3. Hot water supply pressure shall be the same or lower than cold water supply .
4. Ensure that water supply is clean (No Sand, Dirt, Etc.).











MAINTENANCE

Always wipe chrome plated area with dry soft cloth, and sometimes wipe it with cloth soaked in mild soap.

ATTENTION

1. Use of abrasive cleaning material such as; detergents containing hydrochloric acids, thinner, polishing powder, and nylon brush is not recommended
2. Press safety knob turn left to increase temperature over 40°C.
3. Please don't open the thermostat cartridge, because it cause to un stabilize temperature in this product.
4. When insert the cap, please install the flat cap position on front side.(Troubleshooting: Cap Position*)
5. Flow Regulator should not be remove because it could damage the system

INSTALLATION



TROUBLESHOOTING

PROBLEM	CHECK POINT	SOLUTION
Flow rate unsatisfactory	1	Remove and clean
Water leaks around the handle	2	Tighten
Handle is loose	3, 4	Tighten

